



Force of Nature Pro Appliance
For Use with Force of Nature Pro Activator
Capsules

User Guide & Supplemental Information

HCI Cleaning Products, LLC
7 Grassy Lane
Westford, MA 01886

Page 2 intentionally left blank

Thank you for purchasing Force of Nature Pro!

Introduction

This kit contains:

- Pro Appliance & power cord
- 3 Spray Bottles
- 10 Pro Activator Capsules
 - You'll use 1 or 2 Pro Activator Capsules each time you make your multi- purpose cleaner and disinfectant, depending on batch size.
- Quick Start Guide
- User Guide

Please read this entire guide before using your Force of Nature Pro Appliance

**Need help? Contact us at 1-888-985-8099
or go to www.forceofnaturepro.com**

Table of Contents

Introduction	3
Warnings	5-7
Operating Instructions	7-8
Color Code Guide	8
Maintenance	9
Troubleshooting	9-10
Ordering Force of Nature Supplies	10
Warranty	11-13
Supplemental Information	14-20

Warnings



Important safety instructions
Read all instructions before using this product.



Caution: To reduce the risk of fire, electrical shock, damage to the product or injury:

The Force of Nature Pro Appliance is only designed for use in a 110/120/240V outlet.

To avoid electric shock, do not touch the Pro Appliance with wet hands.

If the cord or plug appears damaged, return the cord to Force of Nature by emailing us at support@forceofnatureclean.com and we will replace it.

Power only with included 40V power supply from Merryking, model: MKI-4000250G8

Any attempts to repair the Force of Nature Pro Appliance without written permission from Force of Nature will void the warranty and could cause personal injury to the consumer and/or result in severe damage to the unit.

Do not pull, carry, lift or drag the Pro Appliance by the power cord. Remove the power plug from its outlet by grasping the plug itself and pulling gently.

Use only for cleaning and disinfecting. Do not consume electrolyzed water. Use only in well-ventilated areas.

Avoid contact with eyes. If in eyes, rinse well with water. If irritation persists, seek medical attention.

This product should not affect skin. However, if skin becomes irritated, rinse skin with plenty of water. If irritation persists, seek medical attention.

Do not use to formulate your own homemade cleaner or disinfectant.

Do not clean the Force of Nature bottles with anything but tap water.



Caution: To ensure proper solution concentrations and optimal disinfecting power, follow these instructions:

Do not leave Force of Nature cleaner and disinfectant solution in the Pro Appliance. ALWAYS POUR SOLUTION INTO A SPRAY BOTTLE IMMEDIATELY AFTER COMPLETION OF A CYCLE.

Use Force of Nature multi-purpose cleaner and disinfectant within 14 days after making it. Discard left over solution after 14 days and rinse only with tap water before running a new cycle. Force of Nature maintains its power for 2 weeks. To help you keep track of time, there is a green light around the bottom of the Pro Appliance. After the 2 weeks are up, the light will turn red to remind you to make a fresh batch. If you don't want to keep your Pro Appliance plugged in, write the expiration date on the back of the Spray Bottle.

Add only the required number of Pro Activator Capsules per batch. Do not run more than one cycle per batch of cleaner and disinfectant solution.

Do not use cleaner prior to light ring on Pro Appliance turning completely green.

To Clean

- Spray and then wipe the surface.
- Apply Force of Nature solution directly to a sponge, cloth, rag or mop and then wipe the surface.

To Sanitize

- Clean the surface.
- Spray the surface until thoroughly wet.
- Wait one minute and then wipe the surface.

To Disinfect

- Clean the surface.
- Spray the surface until thoroughly wet.
- Wait 10 minutes and then wipe the surface or let air dry naturally.

Store Force of Nature multi-purpose cleaner and disinfectant in the Spray Bottle at room temperature away from direct sunlight.

Operating Instructions

1. Fill the Pro Appliance with cool water to the desired Fill Line.
2. Plug the power cord into the Pro Appliance and into the outlet.
3. Squeeze in the full contents of one 10ml Pro Activator Capsule if you are creating 32 oz of cleaner, or two 10ml Pro Activator Capsules if you are creating 64 oz of cleaner. Wait 10 seconds for the Activator Capsule solution to disperse.
4. Press the Start button corresponding to the amount of cleaner you want to make: push the button labeled 1 for 32 oz, or the button labeled 2 for 64 oz. Blue lights will begin pulsing, and the lights will begin to transition to green as the cycle continues. The cleaner will be ready after the light ring is completely green.

5. Unplug the Pro Appliance and pour your Force of Nature cleaner into the Spray Bottles. Rinse the Pro Appliance with water before plugging it back in. Press the start button twice in rapid succession to start your day counter.

Force of Nature maintains its efficacy for 2 weeks (14 days). To help you keep track of time, there is a light ring around the bottom of the Pro Appliance that will be green when you first make your cleaner. When you have only 2 days left, the light ring will turn to yellow. At day 14, the light ring will be red, indicating your cleaner has expired – time to make a fresh batch! If you don't want to keep the Pro Appliance plugged in, write the expiration date on the back of the bottle.

When the Spray Bottle is not in use, store upside down on a drying rack.



Empty capsules can be recycled

Color Code Guide for Light Ring

Blue: Your cleaner and disinfectant solution is being made.

Green: Your cleaner and disinfectant solution is ready.

Yellow: Your cleaner and disinfectant solution has two days remaining.

Half Red: The Pro Appliance has not been properly filled with water and/or the proper number of Capsules.

All Red: The cleaner and disinfectant solution has expired or the electrolyzing process did not properly complete.

Maintenance

Water contains minerals such as Calcium and Magnesium. These minerals can accumulate on the Force of Nature Pro Electrolyzer resulting in device failure. To ensure optimal Force of Nature Pro Electrolyzer performance, we recommend descaling the Electrolyzer after every 500 Force of Nature Pro Activator Capsules, or every 3 months, whichever comes first.

Descaling Procedure:

1. Unplug and drain your Force of Nature Pro Electrolyzer
2. Add 32 oz white vinegar (5%)
3. Let the vinegar soak for 2 hours
4. Discard the vinegar
5. Fill the Force of Nature Pro Electrolyzer with water and swirl it around to rinse
6. Discard the water

Troubleshooting

If nothing happens after pressing the desired Start Button:

Unplug the Pro Appliance, wait 20 seconds, then plug it back in at both the outlet and in back of the appliance. Press desired Start Button again. If no response, plug the Pro Appliance into a different outlet and try again.

If the light ring around your Pro Appliance is half red:

The Pro Appliance has not been properly filled with water and/or the appropriate number of 10 ml Pro Activator Capsule(s). Check to make sure that the Pro Appliance is filled to the desired Fill Line with cool water and that you added the corresponding required Pro Activator

Capsule(s): One Pro Activator Capsule for Fill Line 1, or 2 Pro Activator Capsules for Fill Line 2.

If the light ring around your Pro Appliance is all red after you have made a batch:

The cleaner has expired. If the light ring around your Pro Appliance is all red during the making process, the cycle did not properly complete. Unplug the power cord from the Pro Appliance, pour out your solution and re-fill with water to the desired Fill Line. Add the contents of one Pro Activator Capsule for Fill Line 1, or two Pro Activator Capsules for Fill Line 2. Re-plug the Pro Appliance in and press the desired Start Button. If you encounter the issue again, please contact our support team at 1-888-985-8099 or by email at support@forceofnatureclean.com.

If at first the Spray Bottle won't dispense:

Pull the trigger a number of times until the Spray Bottle dispenses. Also ensure you have opened the nozzle of the spray head by twisting it counter-clockwise to open.

Need help? We want you to love your Force of Nature and are here to help! Please contact us at 1-888-985-8099 or go to www.forceofnaturepro.com.

Ordering Force of Nature Supplies

Force of Nature supplies can be purchased by logging in at www.forceofnaturepro.com or a local distributor/reseller.

Warranty

ONE-YEAR LIMITED WARRANTY

Force of Nature's warranty for this product is limited to the terms set forth below:

Force of Nature Warrants this product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original end- user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Force of Nature will either (1) repair the product at no charge, using new or refurbished replacement parts, (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product, or (3) refund the purchase price of the product. When a refund is given, the product for which the refund is provided may need to be returned to Force of Nature and becomes Force of Nature's property.

ITEMS EXCLUDED FROM WARRANTY

This limited warranty does not cover: (a) Damage resulting from accident, alteration, abuse, misuse, flood, fire, earthquake, Acts of God, or other external causes; (b) Cosmetic damage, including scratches, dents, chips, or other damage to the finish of your product, unless such damage results from defects in materials or workmanship and is reported to Force of Nature within 30 days from the date of purchase; and (c) Damage caused by operating the product outside the permitted or intended uses described by Force of Nature.

Force of Nature is not responsible for damage arising from failure to follow instructions relating to the product's use.

DISCLAIMER OF IMPLIED WARRANTIES

FORCE OF NATURE'S RESPONSIBILITY IS LIMITED TO REPAIR OR REPLACEMENT AS DETERMINED BY FORCE OF NATURE IN ITS SOLE DISCRETION. ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN TIME TO THE TERM OF THIS LIMITED WARRANTY. NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE EXPIRATION OF THE LIMITED WARRANTY PERIOD.

Some states, territories, or provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This limited warranty gives you specific rights, and you may also have other rights which vary depending upon your location.

LIMITATIONS OF REMEDIES, EXCLUSIONS OF INCIDENTAL AND CONSEQUENTIAL DAMAGES

YOUR SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR OR REPLACEMENT AS DETERMINED BY FORCE OF NATURE IN ITS SOLE DISCRETION. FORCE OF NATURE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states, territories, or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation and exclusion may not apply to you. This limited warranty gives you specific legal rights, and you also may have other rights that vary depending upon your location.

OBTAINING WARRANTY SERVICE

During the Warranty Period, if a Product or one of its parts qualifies for replacement or service under the Warranty, Force of Nature requests that the customer contact Force of Nature Consumer Support at forceofnatureclean.com for further instructions on the Warranty claim process, to address the Warranty claim, or to otherwise address any steps to repair and/or replace the Product or part.

Force of Nature will send a pre-paid shipping label via email so that the Product may be sent to Force of Nature at no cost to the customer. Upon receipt of the Product, Force of Nature may ship the replacement or contact the customer with further information regarding repair options for the Product. Typical response time to address Warranty claims is up to 60 business days, plus shipping depending on the geographical location of the customer and type of damage or the nature of such Warranty claim.

For additional protection of the Product and to ensure secure handling while the Product is being returned for any Warranty repair, Force of Nature recommends that customers employ Force of Nature's shipping label or a traceable, insured delivery service if directed. Force of Nature is not responsible for any damage while a Product is in transit or for the Products shipped by the consumer that are not received by Force of Nature or a designated Authorized Servicer.

WARRANTY NOTICE TO CALIFORNIA RESIDENTS ONLY

California residents may initiate Warranty service by calling Force of Nature Customer Support toll-free at 1-888-985-8099. California law also provides that for any Warranty service for a Product, California residents have the option of returning the Product (a) to the seller from which it was originally purchased or (b) to another seller that sells the same Force of Nature Product, among other rights and consumer protections California residents need only supply their Proof of Purchase in each case above, or to contact Force of Nature for Warranty service, customer should call Force of Nature Customer Support for specific instructions. Force of Nature will only be responsible for the cost of repair, replacement or reimbursement and shipping and handling for such Products under its Warranty. A seller to which a California Resident returns a Product for Warranty service may refer the customer to Force of Nature Authorized Servicer, replace the Product, or refund the purchase price less the amount directly attributable to the customer's usage of the Product. If the above options do not result in the appropriate remedy to the customer, the customer may then take the Product to an independent repair facility if service or repair can be economically accomplished. Force of Nature, and not the customer will be responsible for the reasonable costs of such service, repair replacement or reimbursement during the Warranty Period for the Product if such Product is subject to Force of Nature Limited Warranty.

Questions? Contact us at 1-888-985-8099 or go to www.forceofnaturepro.com



Supplemental Information

Force of Nature Pro Activator Capsules
For Use with Force of Nature Pro Appliance

DIRECTIONS FOR USE OF FORCE OF NATURE ACTIVATOR CAPSULE (TO GENERATE HYPOCHLOROUS ACID SOLUTION)

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling. Users must follow all directions for use that are listed in the Force of Nature Pro Appliance User Guide.

Note: Force of Nature Pro Activator Capsules are for single use.

The Force of Nature Pro Appliance is designed to use electricity, potable tap water and Force of Nature Pro Activator Capsule to create HOCl (hypochlorous acid) solution. This conversion is accomplished using a process called electrolysis that employs an electrolytic cell. Force of Nature Pro Appliance makes solution on demand as initiated by the User.

1. Fill the Pro Appliance with cool water to the desired Fill Line.
2. Plug the power cord into the Pro Appliance and into the outlet.
3. Squeeze in the full contents of one 10ml Pro Activator Capsule if you are creating 32 oz of cleaner, or two 10ml Pro Activator Capsules if you are creating 64 oz of cleaner. Wait 10 seconds for the Activator Capsule solution to disperse.
4. Press the Start button corresponding to the amount of cleaner you want to make: push the button labeled 1 for 32 oz, or the button labeled 2 for 64 oz. Blue lights will begin pulsing, and the lights will begin to transition to green as the cycle continues. The cleaner will be ready after the light ring is completely green.
5. Unplug the Pro Appliance and pour your Force of Nature cleaner into the Spray Bottles. Rinse the Pro Appliance with water before plugging it back in. Press the start button twice in rapid succession to start your day counter.

This process generates a Hypochlorous Acid solution of 220 ppm Available Chlorine. Users must refer to the directions for use of Hypochlorous acid solution for hard, non-porous surface disinfection.

PRECAUTIONARY STATEMENTS

Physical or Chemical Hazards: Force of Nature Activator Capsule content is not compatible with other chemicals such as bleach or hydrogen peroxide, or any other cleaner or

disinfectant. DO NOT MIX Force of Nature Activator Capsules or Hypochlorous Acid solution with any other product.

Hazards to Humans and Domestic Animals: CAUTION

Causes moderate eye irritation. Avoid contact with eyes. When handling the product, wear safety glasses or goggles if splashing is anticipated. Wash thoroughly with soap and water after handling and before eating, chewing gum, using tobacco or using the toilet.

First Aid: Call a poison control center or doctor for treatment advice. Have the product container or label with you when calling a poison control center, doctor or going for treatment. You may also contact the National Pesticide Information Center (NPIC) 1-800-858-7378 for emergency medical treatment.

If in eyes: Hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye.

Hypochlorous Acid Solution
220 ppm Available Chlorine
Disinfectant for hard, non-porous surfaces
Kills bacteria
Cleans and Deodorizes
See Force of Nature User Guide for more information

DIRECTIONS FOR USE OF HYPOCHLOROUS ACID SOLUTION

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling

Disinfection of Hard, Non-Porous Surfaces using Force of Nature Solution Spray

To Clean, Disinfect and Deodorize Hard Non-Porous Surfaces: Pre-clean surface. Spray Force of Nature disinfecting solution on surface until thoroughly wet. Allow surface to remain wet for 10 minutes. Wipe surface with clean cloth or towel or let air dry.

Sanitization of Hard, Non-Porous Surfaces using Force of Nature Solution Spray

To Clean and Sanitize Hard Non-Porous Surfaces: Pre-clean surface. Spray Force of Nature solution on surface until thoroughly wet. Allow surface to remain wet for 1 minute. Wipe surface with clean cloth or towel or let air dry.

Solution(s) are effective for up to 14 days from production date. After 14 days discard and refill bottle with fresh solution. Always use a Force of Nature approved spray bottle and label to identify product in use.

Solution can be used immediately upon production, or stored for up to 14 days in cool area out of direct sunlight in a closed Force of Nature approved spray bottle.

Force of Nature Disinfectant Solution(s) are intended for use in household, commercial and institutional uses and settings. It cleans, deodorizes, sanitizes and disinfects.

The Force of Nature Pro Appliance is designed to use electricity, potable tap water and Force of Nature Activator Capsules to make an antimicrobial HOCl (hypochlorous acid) solution. This conversion is accomplished by using a process called electrolysis that employs the use of an electrolytic cell. Force of Nature Electrolyzed Water Device will make solution per demand and only require User input when making solution.

The Force of Nature Pro Appliance Solution is designed for use on hard non-porous surfaces in:

- Commercial buildings and floors
- Daycares, Pre-Schools, Schools, universities, and other campus facilities.
- Hotel, motel, casino and other hospitality housekeeping, venues
- High-touch areas and surfaces including but not limited to door handles, door knobs, tabletops, countertops, television, television remotes, video game controllers, chairs, headboards, sinks, faucets etc.
- Homes, hospitals, dentist offices, assisted living facilities, long term care facilities, nursing homes, medical clinics, military facilities, medical offices, veterinary facilities, animal research facilities, cruise ships, farms, laboratories classrooms, food processing facilities, restaurants, hotels, motels, etc.
- Animal Premises. Animal grooming Facilities, Animal Housing Facilities, Animal Life Science Laboratories, and Kennels. Remove all animals and feed from area before use.

Pre-clean surface before applying solution. Spray solution on hard, non-porous surfaces until thoroughly wet. Spread solution with a microfiber, cotton, disposable paper towel, sponge, cloth or other wipes. Allow surface to remain wet for the appropriate time. Wipe surface dry if desired after the appropriate time. No rinsing necessary.

Pathogen	Strain	Contact Time
Organisms Supported for Disinfection		
Pseudomonas aeruginosa	ATCC 15442	10 min

Staphylococcus aureus	ATCC 6538	10 min
Salmonella enterica	ATCC 10708	10 min
Listeria monocytogenes	ATCC 19117	10 min
Methicillin-resistant Staphylococcus aureus (MRSA)	ATCC 33592	10 min
Feline Calicivirus surrogate for Norovirus	VR-782	10 min
Influenza A virus	VR-544	10 min
Organisms Supported for Sanitization		
Salmonella enterica subspecies enterica serovar Typhi	ATCC 6539	1 min

GENERAL CLAIMS

Kills 99.9% of germs* including Staph, MRSA, Salmonella, Listeria and the viruses that cause flu*

Kills 99.9% of bacteria

Multi-purpose cleaner works on virtually any surface

Tough on Germs*

Rinse free disinfectant

Kills Flu

Virus*

Kills 99.9% of germs* on virtually any hard, non-porous surface

Disinfectant Organism List: Pseudomonas aeruginosa, Staphylococcus aureus, Salmonella enterica, Listeria monocytogenes, Methicillin Resistant Staphylococcus aureus – MRSA, Influenza A Virus Strain A/Hong Kong/8/68, Feline Calicivirus Strain F9

Sanitization Organism List: Salmonella enterica subspecies enterica serovar Typhi

Use Sites: For use on hard, non-porous surfaces

Around Toilet Areas

Around Toilets

Automobiles

Animal Equipment

Baby bottles

Baby toys

Baby bathtubs (tubs)

Booster chairs

Bouncy seats

(Bath)tubs

Bathroom (countertops)

Bathroom (surfaces)

Beverage bars

Blinds

Breast Pumps

Door Handles
Doorknobs
Doors
Drainboards
Dryers
(Kitchen) Appliances
(Kitchen) (Bathroom) Sinks
Humidifiers
Children's serve ware
Sippy cups
Straw cups
Water bottles
Lunchboxes
Backpacks
Bath toys
Toothbrushes
Mops
Patio (deck) furniture
Camping gear
Inside refrigerators
after warming to room
temperature.
Refrigerator exteriors
Microwave exteriors
Restrooms
Shower (Faucets)
(Doors) (Handles)
(Fixtures) (Walls)
(Floors)
Sink (Faucets) (fixtures)
(Handles)
Soap Dispensers
Storage Areas
Stovetops
Steering wheel hard
non-porous surfaces
Thermos
Toasters
Toilet [(Flushing)
(handles) (seats)
Shower curtains
Inside Washing
Machines
Garbage (trash) cans

Sports gear
Boat interiors
Breast pump parts
Breast pumps
Cabinet Handles
Cabinets
Can openers
Cars
Car interiors
Changing tables (areas)
(Computer) Keyboards
Counter
Countertops
Car interiors
Cupboards
Diaper pails
Dining Room Tables
Restaurant tables
Bar tables
Waste baskets
Floors
Orthotics
Kitchen counter tops
(Kitchen) (dining room)
Tables
Kitchen surfaces hard
non-porous
Kitchen tools
Laundry Rooms
Light Switches
Litter box
Makeup brushes (&
sponges)
Medicine Dropper
Mouthguards
Range tops
(Salad bar) Sneeze
Guards
Snack counters
Bathroom Fixtures
Bath Tub
Bed heads and frames
Bedpans

Bar counters
Dish Racks
Dishwashers
Glazed Ceramic
Glazed Tile
Chrome
Corian
Food Contact Surfaces-hard
non-porous.
Food Preparation (surfaces)
(areas)
Food serving areas
Food trays
Freezers
Grills
Grocery Carts
(Grocery) Checkout Areas
Handrails
Inside Dishwasher(s)
Hard, Non-Porous
Surface Cabinets
Ceilings
Hard, Non-Porous
Chairs
Classroom Desks
Computer Monitors
and Keyboards
Hard, Non-Porous
Countertops
Counters
Dental Countertops
Dental Operatory
Surfaces
Dental Chairs
Drinking water
fountain
Diaper pails
Elevators
Faucets
Fixtures
Floors
Sinks
Stall Doors
Stretchers

Tables
Exterior surface of
Toilets
Toilet Seats
Inside freezers after
warming to room
temperature
Inside microwaves
Sports gear plastic
helmets Sports gear
plastic pads
Sports gear plastic
gloves
Newborn nurseries
Neonatal nurseries
Neti Pots
Oven doors
Ovens
Pacifiers
Teethers
Baby (Children's)
(Kiddie) (wading) pools
Pet Bowl(s) (Areas)
Pet Feeding Dishes
Pet Cages (crates)
Plastic Pet Toys

Piano Keys
Plastic Cutting Boards*
Plastic Patio Furniture
Potty-Chair(s) (Seats)
Range hoods
Recycling Bins
Food Contact
Surfaces-hard non-
porous
Food Preparation
(surfaces) (areas)
Food serving areas
Food trays
Freezers
Grills
Glass
Garbage or Trash
Cans/Pails
Gurneys
Hampers
Environmental Dental
Surfaces
Frequently Touched
Spots
Keyboards
Lamps

Light Lens Covers
Linoleum
Mirrors
Patient Chairs
Plastic Mattress
Covers
Reception Counters,
Desk and Areas
Shelves
Showers
Toothbrushes
Plastic shower
curtains
Towel Dispensers
Exterior of Urinals
Walls
Wash Basins
Dairy cases
Wheel Chairs
Bed Rails and Frames
Hard Non-Porous
Surfaces in Veterinary
and Animal Research
Labs
Troughs

Use Locations: For use on hard non-porous surfaces

Airplanes
Ambulances
Assisted Living
Facilities
Blood Banks
Boats
Buses
Businesses
CAT Laboratories
Casinos
Colleges
Commercial Buildings
Convenience Stores

Cruise Liners / Ships
Churches
Daycare Facilities
Dentist (Dental) Offices
Dentist (Dental) Chairs
Dental Operator
Rooms
Doctor Offices
Dormitories
Emergency Rooms
Facilities
Factories
Fountains

Funeral Homes
Gas Stations
Government Facilities
Grocery Stores
Gyms
Hotels
Hospital Facilities
Healthcare Facilities
Health Clubs Facilities
Home care facilities
Industrial Facilities
Institutional Buildings
Intensive Care Units

Kitchens	Private Facilities	Automatic Feeders
Laboratories	Processing Plants	Cages / Pens
Laundromats	Public Areas	Veterinary
Locker Rooms	Wineries / Breweries	Environments and
Malls	X Ray rooms	Animal Research Labs
Manufacturing	Yachts	Pet Areas
Facilities	Radiology or X-Ray	Pet Shops and Stores
Manufacturing Plants	Rooms or Areas	Small Animal Facilities
Medical Clinics	Retail Stores	Veterinary and/or
Military Installations	Restaurants	Animal Hospitals
Facilities Nursery	Restrooms and or Rest	Veterinary Clinics or
Schools	Areas	Facilities
Nursing Stations	Shelters	Veterinary Offices
Locker Rooms	Office Buildings	Animal Research Labs
Yoga studios	Orthopedics	Veterinary Clinics
Pharmacies	Veterinary	Veterinary Stores
Physical Therapy	Environments and	Veterinary Hospital
Rooms or Areas	Animal Equipment	

STORAGE AND DISPOSAL

Do not contaminate water, food or feed by storage or disposal or cleaning of equipment.

Pesticide Storage: Store in a closed plastic container in a cool, dry area away from heat and sunlight to avoid deterioration. Do not store near easily oxidizable materials acids and reducers. In case of spill, flush area with large quantities of water.

Pesticide Disposal: Wastes resulting from the use of this product must be disposed of on-site or at an approved waste disposal facility. Product or rinsates that cannot be used must be diluted with water before disposal in a sanitary sewer.

Container Handling: Refillable container. Refill container with Force of Nature solution only. Do not reuse this container for any other purpose. Cleaning before refilling is the responsibility of the refiller. Cleaning the container before final disposal is the responsibility of the person disposing of the container. To clean the container before final disposal fill container half way with water and shake vigorously. Dispose of rinsate as pesticide waste. Repeat this rinsing procedure two more times. Then offer for recycling or puncture and dispose of in a sanitary landfill, or by incineration, or by procedures allowed by state and local authorities.